

Aduamarine Moon Pendant

A Must Keep

Projects

by Aida x

Summary

or birthday gift.

You can change the colour and Using prong settings is the perfect Spacers - 1mm size of the stone to anything you way to be able to use that stone, Roller want. Perhaps use a birthstone without exposing it to the high Sanding Pad instead to make that gift even temperatures of firing. more special.

You learn some great tips with this project including: making your own simple cutters, using embeddable screw eyes, and setting a stone in a prong setting.

Useful Tip

This gorgeous aquamarine moon This project is great for those Flat wire pendant is a not only easy to make, stones that can't be fired. Have Flat Nose Pliers but would make a great christening you got a gorgeous stone that just Badger Balm isn't fire safe?

Materials

Art Clay Silver 650 - Clay Work Surface Art Clay Silver 650 - Syringe Brush Fine Silver Bail Back Insert (can be anything!) Scissors Glue (PVA is fine) **UV** Resin UV Lamp (for curing)



Step 1 Bend some flat wire around a ring Roll out your clay 2.5mm thick. (If Cut out a circle using your large mandrel (or other round object) you have our spacer set, it only has cutter. Cut out another circle within two different sizes. Tape the ends 3mm spacers, so tape the 1mm and will create your moon shape. together, this makes a great handle. 1.5mm together - viola).



Step 2



Step 3

to form your cutter. Do this in 0.75mm, 1mm, 1.5mm, 2mm and this with your smaller cutter, this





Step 4 moon. You may need to trim the help secure it. post a little so it doesn't protrude.



Step 5 Measure your embeddable eyelet Attach the eyelet and prong setting Wipe and/or neaten up any paste and prong setting against your to your moon. Use some paste to that needs it. Use a damp brush for



Step 6 this.



Step 7 setting if needed.



Step 8 satin finish simply use a brass brush. to wear!



Step 9 Once dry, refine any rough edges Fire and finish your piece. Check Place your stone into the prong with a sanding pad. Apply more out our learn more page for more setting and close the prongs around paste to the eyelet and prong firing information. For a simple it. Attach a chain and your ready

